SCHEHERAZADE 2 TIERS with metal ring / **art. 125 SHC** / **silk**

assembly instructions / suspended

LED │ 1 x MAX 15W │ E26 │ 110-120V │ 50-60 Hz

ATTENTION: do not use abrasive products to clean this lamp but only a damp cloth.

Our creations may show slight imperfections due to the special handwork required on each piece.
Variations are one of the features which make each of our products an original and unique item.

GENERAL:

- Read all instructions and review diagrams beginning with the installation of the fixture.
- All electrical connections must be in accordance with local codes, ordinances or national codes. If you are unfamiliar with methods of electrical wiring, secure the services of a qualified licensed electrician.

BEFORE BEGINNING INSTALLATION:

- Turn off the electricity to the outlet box at the circuit breaker or fuse box.
- If you are replacing an existing fixture, remove the old fixture and expose the supply wiring.
- Remove the old cross bar.

ELECTRICAL CONNECTIONS:

- While supporting the fixture, connect the white wire from the fixture to the white or marked wire of the supply circuit.
- Connect the black fixture to the black supply wire. Connect the ground wire - bare copper wire - to the ground conductor of the supply circuit. Secure with UL listed wire connectors suitable for the size, type and number of wires. Make sure that there are no loose strands of wire and that there are no loose connections.
- Spread the electrical wire connections apart and back into the outlet box.

INSTALLING FIXTURE:

1. Before starting the installation, disconnect the power by turning off the circuit breaker or removing the fuse at the fuse box.

2. Attach the cross bar **A** to the outlet box using the outlet box screws.

3. Make the electrical connections. Refer to the section titled Electrical Connections.

4. Place the canopy (element **B**) over the nipple.

5. Screw the hook **C** onto the nipple and tighten securely.

6. Install bulb. Do not exceed the maximum wattage for this fixture. Refer to the wattage warning label attached to the fixture for maximum allowable wattage.

7. Lay the element **D** over a flat clean surface, then lay large disk over element **D** with the larger circumference facing down.

Insert element **E** and tighten the three screws **F** on element **D**.
Make sure that element **D** and **E** are safely fixed to the large disk.

8. Hang the metal ring to the cealing as shown.

E

F

D

large disk

This side up

9. Insert the lampshade through the cords as shown in the picture.

10. Screw the small disk onto element B.

Element B

Connect the medium disk with small disk using the set of cords provided.
To attach medium disk to small disk, pass the cord through the pearls following the path
of the arrows (- - - -) and then make a knot.

11. Hang the hook of the glass drop into the ring of the small disk.

12. Restore the electricity and test.